



UPPERFLOK

A THIN HEAT TRANSFER VINYL WITH A SOFT VELVET FEEL.

Looking for a flock heat transfer vinyl to customize your garments? Upperflok offers a luxurious suede-like feel, an elegant finish and a fashionable look, making it ideal for durable and original creations.

TECHNICAL DATA	
	COMPOSITION Viscose fibers
	THICKNESS 300 µm
	CARRIER Transparent adhesive polyester carrier
CUT SETTINGS	
	SIDE Mirror cut
	CUTTING 60° flock blade
APPLICATION	
	TEXTILE Cotton, polyester, polycotton
	TIME & TEMPERATURE 160°C- 320°F / 20s
	PRESSURE Medium
	PEEL Cold peel

PRODUCT HIGHLIGHTS		
- Outstanding wash resistance up to 60°C / 140°F. - Soft and comfortable to the touch. - Easy to cut using a 60° flock blade. - Quick and easy to weed. - Ideal for lettering and small to medium-sized designs.		

CARE & MAINTENANCE		
- Always follow the care instructions for the garment. - Wash inside out to extend the design's life. - Wait 24 hours after application for the first wash. - Avoid using of aggressive products. - Do not bleach.		

WASHING	IRONING	TUMBLE-DRY
 60°C / 140°F	 Inside out only	 Allowed

STEP BY STEP : HOW TO USE	
STEP 1 - Perform a test cut using your cutting plotter.	
STEP 2 - Mirror cut the heat transfer vinyl using a 60° flock blade.	
STEP 3 - Weed the excess material and apply the design to the garment.	
STEP 4 - Press and cold peel the carrier.	

PRODUCT HIGHLIGHTS

- Outstanding wash resistance up to 60°C / 140°F.
- Soft and comfortable to the touch.
- Easy to cut using a 60° flock blade.
- Quick and easy to weed.
- Ideal for lettering and small to medium-sized designs.

CARE & MAINTENANCE

- Always follow the care instructions for the garment.
- Wash inside out to extend the design's life.
- Wait 24 hours after application for the first wash.
- Avoid using of aggressive products.
- Do not bleach.

WASHING	IRONING	TUMBLE-DRY
 60°C / 140°F	 Inside out only	 Allowed

STEP BY STEP : HOW TO USE

- STEP 1 - Perform a test cut using your cutting plotter.
- STEP 2 - Mirror cut the heat transfer vinyl using a 60° flock blade.
- STEP 3 - Weed the excess material and apply the design to the garment.
- STEP 4 - Press and cold peel the carrier.

CERTIFICATIONS



STANDARD
100
CQ 909/2
IFTH
www.oeko-tex.com



No

Yes

Yes

NOTE: We strongly recommend carrying out cutting, heat press and application tests before production.

CHEMICA SAS 35 rue de Malacussy , 42000 Saint-Etienne, FRANCE