# MAGICFLEX



#### **CARRIER: Non-Adhesive Transparent Polyester**

#### APPLIES ON

- ⊕ Cotton
- ☆ Acrylic & Similar Fabrics

### CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

### WASH

- Max 100°F
- Preferably inside out
- Do NOT bleach
- Do NOT Tumbledry
- Do NOT Dry-clean

#### STORE

- Up to 1 year
- In a dry room (60-85°F)
- Away from sunlight
- In vertical position

## **APPLICATION**

- 1. Cut the material right-reading (DO NOT MIRROR) with the recommended blade
- 2. Weed the excess material
- 3. Use a low-tack application tape to transfer material
- 4. Heat pressing in two steps: 1st: position and heat press the heat transfer on the garment protected by a silicon paper at 320°F 10 sec at the lowest pressure. Remove the application tape immediately after heat pressing. 2nd: heat pressing without application tape at 320°F 30sec at the lowest pressure.

